# w225 lon Instructions

8 ł

Page 1/2

Wästberg Box 5085 200 71 Malmö Sweden wastberg.com



# Mounting instructions

1. There are different mounting accessories to attach the lamp to.

2. Base

Attach the lamp to the base.


## 3. Pin

a) Cord through the table top: Place the cord in the slot inside the pin. Place the pin through a Ø14mm hole with one disc above and one under the table. Secure with washer and nut under the table.

**b)** Cord above the table top: Place the pin through a Ø14mm hole. Secure it with the washer and nut under the table.

4.

Attach the lamp.





w225 lon

7.

6.

Wästberg Box 5085 200 71 Malmö Sweden wastberg.com



## Mounting instructions

#### 5. Wall

Mount the bracket to the wall (screws are not included). Fix the cover with the socket screw and attach the lamp.

### 6. Wall


Mount the bracket to the wall (screws are not included). Fix the cover with the socket screw.


## 7.

Attach the plug to the adapter and connect the power cord.

## 8.

Press to turn the light on and off.The lamp has an 8 hours timer. Press and hold to dim the light.








8.



Ċ







This product contains a light source of energy efficiency class G. To replace the light source, contact customer service at service@wastberg.com