

PENDANTS:	three	
CANOPY:	brushed-nickel canopy 152mm (6") in diameter and 32mm (1.3") deep	
LAMPING:	10w xenon or 1.8w LED	
ENGTH OF COAX:	3000 (10') standard / 30500 (100') maximum	
INSTALLATION:	strain relief (pendant light site adjustable)	
MATERIALS:	cast glass, blown borosilicate glass, braided metal coaxial cable, electrical component: brushed nickel canopy	
WEIGHT:	approximately 5.5kg (12lb)	
TRANSFORMERS	integral	

## DESCRIPTION

14.3 is a random configuration of three 14 pendants hung from a round canopy. The pendants are designed to hang in a random configuration at times clustering and grouping together and others trailing off. The result is an ambient installation or field of light. The pendant drop lengths on this light fixture are adjustable up to the specified maximum.


The 14 is an articulated, seamed cast glass sphere with a frosted cylindrical void that houses a low voltage lamp. Individual pendants are visually quite subtle, but gain tremendous strength when multiplied and clustered in large groups.

## NOTES

- + Purchase replacement lamps online at www.bocci.ca/lamps
- + Unless otherwise noted when ordering, all light fixtures will be outfitted to be xenon compatible.
- Note: As an alternative to a built-in transformer, Bocci recommends mounting transformers remotely in an easily accessible and hidden location for ease of long-term maintenance.

US patent # D556, 361 Worldwide patents issued and pending. Made in Vancouver, Canada

g (12lb) Vancouver sales@bocci.ca www.bocci.ca Berlin europe@bocci.ca www.bocci.ca



## 1

Very carefully uncoil the braided coaxial cable in a spool like manner. Insert your index fingers into opposite sides of the roll then rotate your fingers around each other to unroll the coaxial cable. Use patience: allow the cable to uncoil completely to avoid kinks.

2

Thread the coaxial cable through the canopy.

1

r

Throughout the installation, be mindful not to damage the borosilicate tube inside the pendant.

strain relief	black white white (110V) black (110V) brown (230V) 12V	
3 Determine the overall drop for the pendant fixture. Use the Allen key provided to loosen the setscrew in the canopy and gently feed the cable through the canopy until you have reached your desired drop length. Use Allen key to tighten the setscrew hold the strain relief to secure the coaxial cable at its new length. DO NOT OVERTIGHTEN. Note: The strain relief is a black plastic collar around the coaxial cable. There is a single slot opening on the side of the strain relief component. It is essential that this opening is oriented at 90 degrees to set screw chamber. There can be no contact between the set screw and the cable. - RISK OF ELECTRIC SHORT!	<text></text>	5 Tuck the transformer and wiring into the octagonal box, if available, and place canopy cover plate, lining up the fastener holes or connect directly to structural ceiling surface. Affix canopy cover with fasteners provided. Note: It may be helpful to rest the pendants on a surface higher than its final position so that the canopy may be fastened with greater ease.

ų 1 10W Bocci 24.1 long life xenon bipin or 24.2 LED 7 Bocci 24.1 long life bipin Clean fingerprints from xenon lamps included. Bocci glass surfaces. 24.2 LED lamps optional. Lamping is transformer Turn fixture on. × Plug the lamp into the socket. Do not touch the lamp with For additional assistance, your bare hands. please contact Bocci: Purchase replacement lamps Vancouver online at www.bocci.ca/lamps sales@bocci.ca www.bocci.ca Note: when using a dimmer for xenon, use only low voltage Berlin electronic dimmer to ensure europe@bocci.ca the fixture works properly. www.bocci.ca Worldwide patents issued and pending. US patent # US D556,361 Made in Vancouver, Canada

6

specific.

BOCCI